

# T-Lock Long Sleeve Insert Instructions

## Items Needed for Installing T-Lock Long Sleeve Insert:

### TLOCK LONG SLEEVE PLATEN INSERT - #TLOCKLSV

T-Lock Long Sleeve Insert w/ Wing Nuts (Included with T-Lock Platen Complete Kit)

### H-BASED PLATEN INSERT

T-Lock H-Base Insert (Included with T-Lock Platen Complete Kit)

## Instructions for installing T-Lock Long Sleeve Insert:

Below are instructions for installing the Long Sleeve Insert on your T-Lock Platen with H-Base Insert.



### Step 1:

Remove the Adult Platen by loosening the Locking Lever and lifting the platen straight up.



### Step 2:

Insert the T-Lock Base into the platen stem of the Brother DTG printer.



### Step 3:

Install the T-Lock H-Base Insert so T-Lock brackets slide into the slots in T-Lock Base.



### Step 4:

Secure the Platen Insert by rotating the center piece in the T-Lock brackets.

5



**Step 5:**

Insert the Long Sleeve Insert on to the H-Base Insert and securing using the included wing nuts.

6



**Step 6:**

Adjust the height of the platen to the desired position and tighten Locking Lever.

---

## Click or Scan Below to View the T-Lock Kit Overview Video

---

**Video**



**T-Lock Kit Overview Video**

This video shows at a glance how to install and use all of the inserts included in the T-Lock kit.