

T-LOCK XL INSERT INSTRUCTIONS

Items Needed for Installing T-Lock XL Platen Insert:

TLOCK XL PLATEN INSERT - #TLOCKXLIDIST

T-Lock XL Platen Insert

T-Lock Base - #TLOCKBASE

T-Lock Base needed for using Inserts. T-Lock Base is NOT included with Inserts.

Instructions for installing T-Lock XL Platen Insert:

Below are instructions for installing the XL Platen Insert on your T-Lock Base.



Step 1:

Remove the Adult Platen by loosening the Locking Lever and lifting the platen straight up.



Step 2:

Insert the T-Lock Base into the platen stem of the Brother DTG printer.



Step 3:

Install the T-Lock XL Insert so T-Lock brackets slide into the slots in T-Lock Base.



Step 4:

Secure the Platen Insert by rotating the center piece in the T-Lock brackets.

5




Step 5:

Adjust the height of the platen to the desired position and tighten Locking Lever.

Click or Scan Below to View the T-Lock XL Platen Insert Print Video

Click or Scan Below to View the GTX T-Lock Assembly Video

Video



T-Lock XL Platen Insert Print Video

This video shows the T-Lock XL Platen Insert in action.

Video



GTX T-Lock Assembly Video

Learn how to assemble the T-Lock base.