

GTX300 GRIPPER KIT INSTRUCTIONS


Items Needed for Installing Gripper Kits:

GTX300 Gripper Adult - #GRIPA300

1. One (1) 8.5" Front Gripper Channel
2. One (1) 8.5" Back Gripper Channel
3. Two (2) 11.5" Side Gripper Channels


Instructions for installing Gripper Kits:

Below are instructions for installing the GTX300 Adult Gripper Kit on a GTX300 Printer Platen.




Step 1:

Flip platen upside down and remove the protective wrapping from the Gripper Channels.




Step 2:

Remove the backing from the adhesive foam tape.



Step 3:

Center and place the Front 8.5" Gripper Channel and the Side 11.5" Gripper Channels down the side of the Adult Platen. Ensure the side and front Gripper Channels are installed flush with the edge of the platen.



Step 4:

Center the Back 8.5" Gripper Channel. Ensure that the Back 8.5" Gripper Channel is placed halfway off of the edge of the platen when installed.