SIMPLE USER MANUAL

The CUBE pre-treatment machine



- O Please read before you install always.
- Olf you receive a service that does not abide by the order of installation, the additional cost of the service could occur.
- O Depending on the models, the actual figure of products may differ.

1









2 Method of Operation



Power on the device.



After opening a tray, connect a tube with pre-treatment liquid.



Locate lever forward pre-treatment liquid.



Cleaning liquid bottle conforms to the nozzle. Press the cleaning bottle until you see the pre-treatment liquid.



6 Adjust the spray area.



Raise a T-shirt on the board.



Control the speed lever depending on the injeation quantity.



Press the start button.



Maintenance

Caution: Recommend nozzle cleaning thorough more than once a day

to prevent nozzle clogging.



Turn the lever toward cleaning solution.



Locate the cleaning bottle inside the equipment.



Press the cleaning button for 5~10's.



Keep the cleaning inside of machine in order to use for a long time.



How to clean the nozzle tip



Caution:

- Nozzle tip is supplies.
- Please repeat the following process until the nozzle tip pierced.







Product Warranty

Thank you for purchasing a product of PRINTSYSTEM. Quality guarantee period of this product, is calculated from the date of purchase. Therefore, I hope that you receive adequateservice always received described the date of purchase.

Customer	Name	Tel	
	Product Name	Model name	
	Address		
Agency	Dealer Name	Tel	
	Tel	- donas - la	
	Address		
Warranty period	1 year from date of p	ourchase()

Warranty information

- 1. From the product of your order date, when a failure occurs in the state that was used successfully within one year quality warranty period, we will repair free of charge.
- 2. If the next failure occurs, you will at cost the technology fee and
- parts costs.

 O when a fault occurs by the customer handling carelessness
- O Natural disaster when a fault occurs
- (fire, earthquake, flood, lightning, etc.) by
- O when a fault occurs due to abnormal use of power
- O when a fault occurs due to failure of the connected equipment O Rather than a service center for repair of articles, and repair its own product, when failure issue by modifying

Consultation of guidance

- O How to purchase at the time of PRINTSYSTEM product purchased, the price of the product, if you have any questions Products, etc.,
- O If you are not measures quickly even if the dealer of A / S
- O If you have other disadvantages

Standards of consumer damage compensation

Compensation of consumer harm of this product, please follow the law.

Customer Service Office phone number

A / S, customer service and complaints Phone: 032) 433-7758



Install the cleaned nozzle tip at the same angle with the shirt board.



Make sure that nozzle is working properly.



