

PRETREATcleaner



DE

- Zur Reinigung der Düse
- Zur Lagerung der Düse
- Zur Reinigung des PRETREATmakers

Anwendung zur Gerätereinigung:

Befeuchten Sie ein Tuch mit dem PRETREATcleaner und wischen Sie die Precoatingreste ab.

Anwendung zum Reinigen der Düsen:

Befüllen Sie das Ultraschallgerät mit ca. 2 cm PRETREATcleaner. Legen Sie die Düsen in den Kunststoffkorb des Ultraschallgerätes und reinigen Sie diese.

Erneuern Sie die Reinigungsflüssigkeit wöchentlich. Tragen Sie zu Ihrer eigenen Sicherheit Schutzhandschuhe.

Best.Nr. 807068

EN

- For cleaning the nozzle
- For storing the nozzle
- For PRETREATmaker cleaning

Application for cleaning of the machine:

Wet a cloth with PRETREATcleaner and wipe the machine clean.

Application for nozzle cleaning:

Fill up the ultrasonic device with 2 cm of PRETREATcleaner. Place the nozzles in the plastic basket of the ultrasonic device and clean them.

Renew the cleaning solution on a weekly basis. Wear protection gloves for your own safety.

Order.No. 807068

www.pretreatmaker.com